

PARTS LIST

SDRP - SEEDER

<u>PART #</u>	<u>DESCRIPTION</u>	<u>WEIGHT</u>
PSDL	SEEDER DRIVE-LINE	11
PSGB	SEEDER GEARBOX	9.5
PSB	SEEDER BUSHING	0.5
PSP	SPREADER PLATE	5
PSSPF	FLAPS FOR SPREADER PLATE (SOLD SEPARATE)	0.3
PSAP	BOTTOM ADJUSTMENT PLATE	0.8
PSPC	PLASTIC CONE	35
PSA	SEEDER AGITATOR	
PSHW	HARDWARE KIT	